






















# CLUSTER GUIDE

KENWORTH T680, T880, W990



 Coolant Level Low	 Stop Engine Lamp	 Tractor ABS Malfunction
 Check Engine Lamp	 Low Voltage Disconnect	 Park Brake On
 Refrigerator On	 Engine Fan On	 Brake Air Low
 Malfunction Indicator Lamp (MIL)	 High Exhaust Temperature	 Brake System Malfunction
 Seat Belt	 DPF Full or Inhibited	 Wait To Start Engine
 High Beam On	 Trailer ABS Malfunction	 Traction Control
 Service Transmission	 Hill Hold	 Interaxle Differential Lock



# Auto-Start Quick Reference Guide

## Arming Auto Start Stop

1. Satisfy all **Safety Interlock Conditions**
2. Key in **ACC** or **OFF** Position
3. Press and hold Auto Start Stop dash switch in **UP** position for **3 seconds**
4. AUTO graphic will illuminate in dash when ENABLED



## Safety Interlock Conditions

- Hood Closed
- Parking Brake Set
- Neutral Gear Selected
- Check Engine Lamp Off
- Stop Engine Lamp Off
- PTO Switch Disabled
- EOA Switches Disabled



## System Interrupts

- Brake Pedal Press
- Clutch Pedal Press
- Auto Start Stop Dash Switch Turned Off
- Key Switch in Ignition Position



**IMPORTANT:** If Auto Start Stop system is interrupted, the system will need to be manually re-engaged!



# Auto-Start Quick Reference Guide


## Arming Auto Start Stop

1. Satisfy all **Safety Interlock Conditions**
2. Key in **ACC** or **OFF** Position
3. Press and hold Auto Start Stop dash switch in **UP** position for **3 seconds**
4. AUTO graphic will illuminate in dash when ENABLED




## Safety Interlock Conditions

- Hood Closed
- Parking Brake Set
- Neutral Gear Selected
- Check Engine Lamp Off
- Stop Engine Lamp Off
- PTO Switch Disabled
- EOA Switches Disabled



## System Interrupts

- Brake Pedal Press
- Clutch Pedal Press
- Auto Start Stop Dash Switch Turned Off
- Key Switch in Ignition Position




**IMPORTANT:** If Auto Start Stop system is interrupted, the system will need to be manually re-engaged!



## Detailed ACC - Setting

Detailed ACC Setting can be toggled ON and OFF through the Settings Menu. When Detailed ACC is enabled, the Adaptive Cruise Control screen will show the lead vehicle speed and headway data.



Detailed ACC - OFF



Detailed ACC - ON

### To turn Detailed ACC ON or OFF:

- Use the scroll wheel on the right steering wheel switch pod to navigate and select items.
- With the vehicle parked, press the scroll wheel to enter the settings menu.
- Navigate to General > Features > Detailed ACC

